

# Important Changes in New GB5s

## 1) No clear of running step

In the previous versions of the GB5 you could change any step, even if it were running. If the time of a currently running step were changed, it would have to be first cleared (set to zero) which would probably cause the program to return to idle. Consequently, the new GB5s do not allow the changing of a step while it is running, although you can change other steps of a running program, or, of course, any programs which are not running.

Also, you can no longer clear a whole program which is running. If you wish to clear it, you must first force it to idle mode. This is because clearing the whole program would mean clearing the running step, which we just said above is not allowed.

## 2) Entering program mode while running a profile

In the previous versions of the GB5 when you pushed the mode button you always went to the first step of the program. In the newer GB5s, if you push the mode button while a program is running, you go directly to the step which is currently running, since this is assumed to be the one of most current interest! If you wanted to view previous steps, simply use the sequence "A","E" to back up one step (as has always been the case.) Do this as many times as necessary to get back to the step you want to look at.